place . Please avoid any water or rain fall in the machines, if water and rain fall in, turn off the power immediately. The room for cool should be at least 30cm. Keep far away from children, fire, explosive and flammable things, and avoid scalding.

3. When the fog or bubble fluid is used up, you should add fog or bubble liquid in time. If the machine work without fluid, the pump and other parts will get damaged. When adding fluid, remember to turn off the power, and carefully avoid spilling over to cause short cut.

4. The machine should work under professional worker's supper vision, please do not add flammable liquids, gas or perfume into the fluid tank.

6. When working, do not touch the machine and power cord..

7. When long time no use or after use, please disconnect power or unplug the power cord.

Instructions .....■

1. Warranty period: maintenance free within one year (The warranty is valid from the date of purchase。）

2. The warranty is void when:

A. The device has been faulty operate or improper use. Like: burnt caused by overload or over voltage.

B. The device damaged due to moving it.

C. The device cause by poor use environment. Like : moisture, unstable voltage etc.

D. The product has been altered by anyone other .

3. Exclusions: packaging materials, casing and bracket of the product and battery inside wireless remote controller.

4. We won't charge any maintenance and spare parts if the products in conformity with the terms of warranty. In regard to the products which exceed warranty period , we'll only charge the cost of the spare parts accordingly.

1600W SMOKE & BUBBLE MACHINE

MANUAL



Please read this manual carefully before using

Thank you for having chosen our company's bubble&fog machine. For your own safety, please read this user manual carefully before installing the device.

When receiving the machine, open the package and check carefully whether the machine is damaged or the accessories are lost, if any problems, please contact the supplier.

Name	Quantity
Smoke&bubble machine	1piece
Power cord	1 piece
Manual	1 piece
Remote controller	1piece

Specifications ……■

Power: 1600W
Voltage: AC220V 50Hz
Bubble storage tank capacity: 5L
Smoke oil storage tank capacity: 3L
Coverage: 30-50 square meters
Control mode: LCD+DMX+remote control
Spray distance: 8 meters
N. G.: 21.55 kg
W. G: 35.5 kg
Machine size: 39.5 * 37.5 * 47.5CM

Guidance ……■

1. This product can be installed in high places(with hanger), then the effect is better.
2. Before connecting this unit to the mains power supply, you must add the fluid tank with high quality fog &bubble fluid and check that the nozzle is clean and unobstructed.
3. Before connect to power, you should check whether the voltage you use is suitable for the snow machine or not.
5. Power cord should be plugged into a grounded electrical outlet,put the switch to "ON", connect the controllers with the snow machine, then you can control the machine by the controllers.

Control Mode……■

1. LCD display menu

Warming Up：xx% Ready Start
Work Model：A、Fog & Bubbles B、Fog C、Bubbles

DMX Address 001 :

Fog Volume：（1-100%） Wind Volume：（1-9）9-12V
Bubbles Moto：（1-9）9-12V Bubbles Wind Set :（1-9） 9-12V
DC Pump Set: （1-9） 6-12V Interval Set :5-200
Duration Set: 1-200 Fluid Sensor :ON/OFF
Remote Set :ON /OFF

2.Press the timing and quantitative key to display the countdown of the timing and quantitative operation status.

3.When you press the lock working key, the corresponding working mode will be displayed. Pressing the jog key will also display the corresponding working mode. For example: Fog&Bubbles Running Fog Running Bubbles Running

4.Wireless control : Press the A button to start the A, B, C bubble functions set by the menu, and press it again to stop the operation.

5.DMX control: 3 channels

Channel 1: smoke volume ： 0-5 close 6-255 working
Channel 2: Bubble Control :1-4 rollers Sequential control
0-5 is off, --6-60 the first roller works,---61-120 the first and second rollers work, 121-180 the first, second and third rollers work, --181-255 the first, second, third and fourth rollers work at the same time.
Channel 3: Wind volume and bubble volume adjustment (wind speed and water pump strength for extracting bubble oil).

Notice ……■

1. This fog&bubble machine should be used in dry and well-ventilated